

























Stock Colours

		EURO FINISH					
LIGHT COLOURS (LRV 56 - 100)	Benjamin Moore Colours						
	Tan AF-80	Mascarpone AF-20	White 2131-70	Almond Bisque 269	Sandalwood 273	Horizon OC-53	
							
	Gentek Colours						
	Almond (532)	Sandstone (540)	Bright White (431)	Maize (502)	Sandalwood (508)	Pearl (534)	
							
DARK COLOURS (LRV 0 - 55)	Benjamin Moore Colours						
	Clay AF-155	River Rock 2139-10	Black 2127-10	Blue HC-159	High Park 467	Escarpment CC-518	
							
	Gentek Colours						
	Pebble (559)	Commercial Brown (562)	Midnight Surf (509)	Wedgewood Blue (535)	Sable (547)	Storm (570)	
							

*** Custom Colours & Stains**
Custom surcharge will apply
Speak with your PrestigeDIY
Representative for more information.

Stock Paint: 30% Surcharge on
Material Value

Dark Colours
* Dark Colour Paints have
heat reflective qualities.

Standard **EURO FINISH** on all
dark painted products.

Stock Stains



Cherry
DD#9571



Teak
DD#9512



Espresso
DD#9575



Mahogany
DD#9509

Stain Finishes on Prestige DIY Products!

Stock Stain: 45% Surcharge on
Material Value with Top Clear Coat



Espresso Stain

Note: Colours may vary from above chart. All colours to be signed off on before production.

5 Year Limited Paint Warranty.

For further information please visit us at prestigediy.com

Preparation & Application

Your Prestige DIY Products™ are manufactured using premium free-foam cellular PVC and do not require painting to validate the warranty. If painting is preferred, please use the guidelines below.

Surface Preparation

Prestige DIY Products™ can be painted to achieve the desired look or accent colour of your home. To ensure good paint adhesion, the surface of the pvc product should be clean, dry, and free of dirt, mildew, chalk, grease and any other surface contaminants before paint application. Prior to cleaning it is a good practice to fill any holes and remove any marks or blemishes that may appear during the installation process with an exterior filler, (for example, sandable Bondo).

Cleaning can be accomplished using a cloth and a mixture of mild detergent and water. Other cleaning agents include a mild household spray cleaner, a degreaser, or alcohol.

Coating Specification

A 100% acrylic latex or 100% acrylic latex with a urethane additive should be used to achieve superior coating durability and flexibility. Only light to medium coloured paints with a light reflective value (LRV) of 55 units or greater should be applied to Prestige DIY Products™. *Using a paint with a LRV below 55 units will void our product warranty.*

Paint manufacturer recommendations include priming with an exterior 100% acrylic latex primer, followed by two coats of exterior 100% acrylic latex satin finish paint.

Application

Apply paint when the air and surface temperatures are 2°C (35°F) or above, and when the air and surface temperatures will remain above this temperature for the next 24 hours. Avoid painting early in the morning or late in the day when dew and condensation are likely to form, or when rain or snow is threatening. To prolong the shelf life of the paint, always protect it from freezing.

Apply primer and topcoats using the following methods:

- Brush: Use a nylon/polyester brush.
- Roller: Use a 3/8" – 3/4" nap synthetic roller.
- Spray: Airless Pressure...2000 psi Tip...015"-019"

Typical Drying Times (Dry Time at 25°C (77°F); 50% Relative Humidity):

- To the Touch: 30 minutes - To Recoat: 4 hours
- To Handle: 1 hour - To Full Cure: 30 days

Considerations

- Higher quality paints typically outperform lower quality paints.
- Temperature, humidity, wind, and the amount of direct sunlight at time of application will affect paint drying times.
- Prestige Products™ are impermeable to moisture; it may take as long as 45 days for paint application to fully cure.
- Paint failures on wood are due primarily to moisture cycling. Since Prestige Products™ cannot absorb moisture, paints will adhere better and for a much longer time when applied to premium PVC versus wood.

Disclaimer: Decor Innovations is not liable for paint used on Prestige DIY Products™ and/or the result of its use.

