

### Thank you for purchasing Prestige Shutters.

Your Prestige Shutters™ have been designed for an easy, straightforward installation. It is recommended that all products are measured before installation to ensure fit. The user is responsible to verify sizes are appropriate.

#### Tools Needed:

Cordless Screwdriver, Tape Measure, Pencil, Fasteners see Fig #2 for suggestions

#### For Brick / Concrete/ Masonry and Siding Applications:

1. Lay shutter face up on a clean, soft surface. Preferably a piece of cardboard or plywood for drilling purposes.
2. Measure 2" inches down from the top and up from the bottom of the shutter side rails. Mark the rail hole locations as noted in Fig#1, drill a 1/8" diameter hole in line for best even visual layout.
3. Position the shutter on the house next to the window.
4. Using a punch or other suitable marker, mark the mounting hole locations on the building.
5. For good support attach furring strips of pressure treated wood 1" thick by 2" wide to the side of the house, covering the mounting hole locations. Fasten using tapcons or other suitable fastener (not supplied).
6. Mount the shutter with the supplied Finish Trim Screws fastening to the pressure treated wood.
7. Refer to Fig #1a for shutters under 60" high or Fig #1b for Shutters over 60" High, to determine the quantity of fasteners for required shutter height.

#### NOTE: Tips for better installation.

Air gap will allow for venting of heat build up.

When installation is desired on rough stone use PVC pipe cut to desired size for spacer will allow for best 'flat' installation.

**Congratulations,** your Prestige Shutters™ should now be complete and ready to enjoy. While painting is not required, your shutters can be painted a wide variety of colours. In some cases exposed cell structure can hold dirt. For optimal appearance painting can be considered. For more information, please see the available painted instructions at [www.prestigedi.com](http://www.prestigedi.com).

For installation videos, and more information visit us at:

**[WWW.PRESTIGEDI.COM](http://WWW.PRESTIGEDI.COM)**

